



Kiilto Pro Tevan Panox

200

Disinfectant



A ready-to-use surface disinfectant based on hydrogen peroxide and peracetic acid. For disinfecting most hard materials and textile surfaces. Can be used in professional kitchens, industrial use and in other institutions and real estate. For body fluid stain disinfection in health care and other premises. Also suitable for use on surfaces and utensils in the food industry.

Application

For professional use. Suitable for most hard materials, textile surfaces and secretion stain.

Product properties

Residue-free, broad-spectrum microbicidal and efficient disinfectant for disinfecting surfaces and body fluid stains.

The product does not leave wipe marks. The disinfecting efficacy on bacteria, viruses, fungi, moulds and spores has been proven (contact time 5 min.). The efficacy is based on the oxidation reaction caused by hydrogen peroxide.

EN 13697, EN 13727 bacteria
 EN 13697, EN 13624 fungi
 EN 14476 viruses (incl. norovirus, adenovirus)
 EN 13704 spores

Instructions for use

Surface disinfection: Apply the appropriate amount of liquid onto a cloth or surface and wipe. Make sure there is enough moisture: the surface needs to be moist for disinfection to happen. In normal use, disinfected surfaces do not need to be rinsed.

Disinfection of body fluid stains: If there is a large amount of body fluid, first absorb the fluid onto a disposable, absorbent paper tissue or cloth. Then disinfect the stained area. Make sure there is enough moisture. Small or dried up body fluid stains can be disinfected without getting rid of the fluid first.

Once the surface has dried it has been disinfected.

In the food industry the product can be used for disinfecting surfaces, utensils and dishes. Moist surfaces that come into contact with foodstuffs must be rinsed and allowed to dry completely.

Note

Make sure the surfaces can withstand the effects of an acidic cleaning agent. Not suitable for marble, brass, silver, copper or galvanized steel. If required, rinse the surface after disinfection. Do not mix the disinfectant with other cleaning products. The product must not be poured back into the original package.

Composition**Ingredient****Effect**

Hydrogen peroxide	2 %	Biocide
Peracetic acid	<0,1 %	Stabilizing agent, biocide

Product pH

2.0 acidic

Storage

Shelf life 2 years from manufacturing. Do not freeze. Keep the product in a cool, dry place, protected from sun light.

Country of manufacture

NETHERLANDS

User and environmental safety

Use biocides safely. Always read the label and product information before use.

When released, hydrogen peroxide becomes water and oxygen. The containers are made of HDPE, completely recyclable plastic that can be disposed of by burning.

Package size / Product code

Sales unit	Product Code	GTIN	GTIN (sales unit)
6 x 1 l	8071	6417964080711	6417964485189
1 x 5 l	80556	6417964805567	
6 x 750 ml	41061	6417964410617	6417964485196

**Additional information**

Check the updated version of a paper brochure on our website at www.kiilto.com or send an e-mail to our customer service at asiakaspalvelu@kiilto.com.